



Modeling Impedance in the Lithium-Ion Battery

Introduction

Electrochemical impedance spectroscopy (EIS) is a valuable method to investigate electrochemical systems such as batteries. For a battery, where potential perturbations of varying frequency are applied on an electrode, the impedance response gives insight into several battery properties and processes. At high frequencies, short time-scale processes such as capacitance, electrochemical reactions, and local resistances affect the impedance. On the other hand, at low frequencies, diffusion in the electrolyte and active material particles (that is, large time-scale processes) contribute to the impedance.

This example simulates the impedance of a full lithium-ion battery cell using the Lithium-Ion Battery interface with an AC Impedance Stationary study. The model also reproduces the results by Abraham and others ([Ref. 1](#)) for sinusoidal potential perturbations between 10 mHz to 1 kHz after model fitting using the Parameter Estimation study step.

Note: This tutorial model requires the Optimization Module.

Model Definition

The model consists of the following components:

- Negative porous electrode: LTO ($\text{Li}_4\text{Ti}_5\text{O}_{12}$) active material, electronic conductor, and filler.
- Separator: Celgard 2325
- Positive porous electrode: NCA ($\text{LiNi}_{0.08}\text{Co}_{0.15}\text{Al}_{0.05}\text{O}_2$) active material, electronic conductor, and filler.
- Electrolyte: 1.2 M LiPF_6 in EC:EMC (3:7 by weight)

A 1D model with three domains of different thickness is used: a 115 μm negative electrode, a 50 μm separator, and a 35 μm positive electrode. The model is set up in a similar fashion as the [1D Isothermal Lithium-Ion Battery](#), but with double-layer capacitances on the active electrode materials and on the electronic conductor in the positive electrode. The model approach using an additional double-layer at the electronic conductor has, for example, been used by Brown and others ([Ref. 2](#)) to describe experimental EIS spectra measured between 1 mHz and 1 kHz on NCA electrodes.

An AC Stationary Impedance study is used to solve the problem, implying that all variables are shifted from being time dependent to frequency dependent, as illustrated with the following expression:

$$n = n_0 + \text{Re} \{ \tilde{n} \cdot e^{2\pi f \cdot it} \}$$

where n is the variable and subscript 0 denotes the initial value around which the perturbation takes place and tilde the complex perturbation. Furthermore, i is the imaginary unit, f the frequency, and t the time.

The boundary of the positive electrode current-collector is set to a sinusoidal perturbation with a 10 mV amplitude and the boundary of the negative electrode current-collector fixed to 0 V, that is, ground.

The cell impedance, Z (SI unit: $\Omega \cdot \text{m}^2$), is calculated at the boundary of the positive electrode current-collector as follows:

$$\tilde{Z} = \tilde{\phi}_s / (\mathbf{n} \cdot \tilde{\mathbf{I}}_s)$$

where ϕ_s (SI unit: V) is the potential, \mathbf{n} the boundary normal and \mathbf{I}_s (SI unit: Am^{-2}) the current density in the solid. (Note that the `lindex` operator is used in the model file in order to use the perturbing values of the variables in the evaluation.)

Subtracting the reference electrode potential from the solid potential in the numerator enables the analysis of the impedance of the NCA positive electrode versus the reference electrode, thus separating the contribution of each electrode to the impedance. The LTO impedance versus the reference is consequently given by the difference between the cell impedance and NCA impedance versus the reference.

The model is computed for frequencies between 10 mHz and 1 kHz. This range is common in EIS to minimize any errors from experimental interference (for example, [Ref. 2](#)).

OPTIMIZATION

The model is initially solved for the presented experimental set-up ([Ref. 1](#)) with the aid of parameters given in [Ref. 2](#). However, since the simulated impedance deviates to a large extent from the experiments, an optimization is performed using the Parameter Estimation study step. Global Least-Squares Objective is set to minimize the least-squares

error between the simulated and measured NCA impedance versus the reference electrode through variation of some control parameters. These parameters are given in [Table 1](#).

TABLE 1: CONTROL PARAMETERS WITH BOUNDS FOR A CELL VOLTAGE OF 2.30V.

Control parameters	Initial value	Bounds
Exchange current density NCA	1 Am^{-2}	Lower: 1 Am^{-2} Upper: 6 Am^{-2}
Double-layer capacitance NCA	$5 \cdot 10^{-1} \text{ Fm}^{-2}$	Lower: $1 \cdot 10^{-1} \text{ Fm}^{-2}$ Upper: 1 Fm^{-2}
Film resistance NCA	$1 \cdot 10^{-4} \Omega \text{m}^2$	Lower: $1 \cdot 10^{-6} \Omega \text{m}^2$ Upper: $5 \cdot 10^{-3} \Omega \text{m}^2$
Volumetric double-layer capacitance positive electronic conductor	$1 \cdot 10^5 \text{ Fm}^{-3}$	Lower: $1 \cdot 10^5 \text{ Fm}^{-3}$ Upper: $3 \cdot 10^5 \text{ Fm}^{-3}$

The first three parameters have bounds selected as anticipated by the information given by Abraham and others ([Ref. 1](#)). The last parameter depend on the size of the electronic conductor particles. It is also common to run parametric sweeps before selecting control parameters and to narrow down the bounds. Normally the optimization time is reduced and the optimization accuracy is improved when few control parameters and narrow bound intervals are selected.

STUDY SETTINGS

The problem is solved with an AC Impedance, Initial Values study. The optimization solver is set up by adding a Parameter Estimation study step to the study and selecting the IPOPT method with the numeric gradient method.

Results and Discussion

Simulated and experimental Nyquist spectra from the LTO/NCA cell at 2.30 V are displayed in [Figure 1](#). The simulation utilizes the parameters from [Ref. 2](#). Characteristic semi-circles and low-frequency tails are seen. The largest contribution to the cell impedance is in the positive NCA electrode. The difference between the experimental and simulated impedance spectra of the NCA electrode versus reference is evident: The

simulation shows one large semi-circle and an indication of another semi-circle at high frequencies. The experimental spectrum has a smaller depressed (elongated) semi-circle.




Figure 1: Simulated and experimental Nyquist spectra for 10 mHz to 1 kHz. Parameters taken from Ref. 2.

Since the difference is most prominent in the semi-circle frequency region (that is, mid-high frequencies) mainly the parameters describing short time-scale processes do not fit

the experiments. Four of these parameters are investigated with a parametric sweep to determine their impact on the impedance. The sweep is shown in Figure 2.




Figure 2: Nyquist plots when testing the impact of five parameters for 10 mHz to 1 kHz.

As a comparison, the sweep also includes variation of the radius of the positive electrode material particles, mainly affecting the large time-scale process of diffusion in the particles. Its impact is therefore more evident at lower frequencies. This is seen in Figure 2, where both the angle and shape of the low-frequency tail change. The results also show that the parameters describing large time-scale processes seem to be quite accurate in the model.

These findings are consistent with the observations by Abraham and others (Ref. 1) indicating that the electrochemical reaction is less limited in their electrodes. With this

input Table 1 is set up and the optimization is run. The resulting spectra are shown in Figure 3.




Figure 3: Nyquist spectra with optimized parameters for 10 mHz to 1 kHz. Squares denote the data points used in the optimization.

The simulated and experimental spectra for NCA versus reference are now seen to overlap well. The optimized control parameters are tabulated in Table 2.

TABLE 2: CHANGE OF CONTROL PARAMETERS AFTER OPTIMIZATION.

Control Parameters	Optimized Value
Exchange current density NCA	2.6 Am^{-2}
Double-layer capacitance NCA	$6.0 \cdot 10^{-1} \text{ Fm}^{-2}$
Film resistance NCA	$1.0 \cdot 10^{-6} \Omega\text{m}^2$
Volumetric double-layer capacitance positive electronic conductor	$1.9 \cdot 10^5 \text{ Fm}^{-3}$

References

1. D.P. Abraham, S. Kawauchi, and D.W. Dees, “Modeling the impedance versus voltage characteristics of $\text{LiNi}_{0.8}\text{Co}_{0.15}\text{Al}_{0.05}\text{O}_2$ ”, *Electrochim. Acta*, vol. 53, pp. 2121–2129, 2008.


2. S. Brown, N. Mellgren, M. Vynnycky, and G. Lindbergh, “Impedance as a Tool for Investigating Aging in Lithium-Ion Porous Electrodes. II. Positive Electrode Examination,” *J. Electrochem. Soc.*, vol. 155, p. A320, 2008.

Application Library path: Battery_Design_Module/Batteries,_Lithium-Ion/li_battery_impedance




Modeling Instructions

From the **File** menu, choose **New**.

NEW

In the **New** window, click  **Model Wizard**.


MODEL WIZARD

- 1 In the **Model Wizard** window, click  **ID**.
- 2 In the **Select Physics** tree, select **Electrochemistry>Batteries>Lithium-Ion Battery (liion)**.
- 3 Click **Add**.
- 4 Click  **Study**.
- 5 In the **Select Study** tree, select **Preset Studies for Selected Physics Interfaces>AC Impedance, Initial Values**.
- 6 Click  **Done**.

GLOBAL DEFINITIONS

Load parameters from a text file.


Parameters

- 1 In the **Model Builder** window, under **Global Definitions** click **Parameters I**.
- 2 In the **Settings** window for **Parameters**, locate the **Parameters** section.
- 3 Click  **Load from File**.
- 4 Browse to the model's Application Libraries folder and double-click the file `li_battery_impedance_parameters.txt`.

DEFINITIONS

The impedance is calculated using variables defined in a text file. It is defined at the rightmost boundary versus ground (at the leftmost boundary) or a reference electrode. The `lindev` operator explicitly evaluates the deviation from the stationary solution in the perturbed solution.

Variables 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)** right-click **Definitions** and choose **Variables**.
- 2 In the **Settings** window for **Variables**, locate the **Variables** section.
- 3 Click  **Load from File**.
- 4 Browse to the model's Application Libraries folder and double-click the file `li_battery_impedance_variables.txt`.

GEOMETRY 1

Interval 1 (i1)

- 1 In the **Model Builder** window, under **Component 1 (comp1)** right-click **Geometry 1** and choose **Interval**.
- 2 In the **Settings** window for **Interval**, locate the **Interval** section.
- 3 In the table, enter the following settings:

Coordinates (m)
0
L_neg

Interval 2 (i2)

- 1 In the **Model Builder** window, right-click **Geometry 1** and choose **Interval**.
- 2 In the **Settings** window for **Interval**, locate the **Interval** section.
- 3 From the **Specify** list, choose **Interval lengths**.
- 4 In the **Left endpoint** text field, type `L_neg`.
- 5 In the table, enter the following settings:



Lengths (m)
L_sep

Interval 3 (i3)

- 1 Right-click **Geometry 1** and choose **Interval**.



- 2 In the **Settings** window for **Interval**, locate the **Interval** section.
- 3 From the **Specify** list, choose **Interval lengths**.
- 4 In the **Left endpoint** text field, type $L_{neg}+L_{sep}$.
- 5 In the table, enter the following settings:

Lengths (m)
L_{pos}

- 6 Click  **Build Selected**.
- 7 Click the  **Zoom Extents** button in the **Graphics** toolbar.

ADD MATERIAL


The cell materials are available in the Battery Material Library.

- 1 In the **Home** toolbar, click  **Add Material** to open the **Add Material** window.
- 2 Go to the **Add Material** window.
- 3 In the tree, select **Battery>Electrolytes>LiPF₆ in 3:7 EC:EMC (Liquid, Li-ion Battery)**.
- 4 Click **Add to Component** in the window toolbar.
- 5 In the tree, select **Battery>Electrodes>LTO, Li₄Ti₅O₁₂ (Negative, Li-ion Battery)**.
- 6 Click **Add to Component** in the window toolbar.
- 7 In the tree, select **Battery>Electrodes>NCA, LiNi_{0.8}Co_{0.15}Al_{0.05}O₂ (Positive, Li-ion Battery)**.
- 8 Click **Add to Component** in the window toolbar.
- 9 In the **Home** toolbar, click  **Add Material** to close the **Add Material** window.

DEFINITIONS

Use a domain point probe to retrieve the potential in the middle of the separator where the reference electrode is located.


Reference Electrode (RE) Probe

- 1 In the **Definitions** toolbar, click  **Probes** and choose **Domain Point Probe**.
- 2 In the **Settings** window for **Domain Point Probe**, type Reference Electrode (RE) Probe in the **Label** text field.
- 3 Locate the **Point Selection** section. In row **Coordinate**, set **x** to $L_{neg}+L_{sep}/2$.

Point Probe Expression 1 (ppb1)

- 1 In the **Model Builder** window, expand the **Reference Electrode (RE) Probe** node, then click **Point Probe Expression 1 (ppb1)**.
- 2 In the **Settings** window for **Point Probe Expression**, type RE_phi in the **Variable name** text field.

Integration 1 (intop1)

- 1 In the **Definitions** toolbar, click  **Nonlocal Couplings** and choose **Integration**.
- 2 In the **Settings** window for **Integration**, locate the **Source Selection** section.
- 3 From the **Geometric entity level** list, choose **Boundary**.
- 4 Select Boundary 4 only.


LITHIUM-ION BATTERY (LIION)

Set up the model with a negative and a positive porous electrode with a separator in between. Double layers exist on both active materials.

Separator 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)>Lithium-Ion Battery (liion)** click **Separator 1**.
- 2 In the **Settings** window for **Separator**, locate the **Porous Matrix Properties** section.
- 3 In the ϵ_1 text field, type eps1_sep.
- 4 Locate the **Effective Transport Parameter Correction** section. From the **Electrolyte conductivity** list, choose **User defined**. In the f_1 text field, type eps1_sep^brug1_sep.
- 5 From the **Diffusion** list, choose **User defined**. In the f_{D1} text field, type eps1_sep^brug1_sep.

Porous Electrode 1

- 1 In the **Physics** toolbar, click  **Domains** and choose **Porous Electrode**.
- 2 Select Domain 1 only.
- 3 In the **Settings** window for **Porous Electrode**, locate the **Electrode Properties** section.
- 4 In the σ_s text field, type sigmas_neg.
- 5 Click to expand the **Film Resistance** section. From the **Film resistance** list, choose **Surface resistance**.
- 6 In the R_{film} text field, type Rfilm_neg.
- 7 Locate the **Porous Matrix Properties** section. In the ϵ_s text field, type epss_neg.

- 8 In the ϵ_1 text field, type `eps1_neg`.
- 9 Locate the **Effective Transport Parameter Correction** section. From the **Electrolyte conductivity** list, choose **User defined**. In the f_1 text field, type `eps1_neg^brug1_neg`.
- 10 From the **Diffusion** list, choose **User defined**. In the f_{DI} text field, type `eps1_neg^brug1_neg`.

Particle Intercalation 1

- 1 In the **Model Builder** window, click **Particle Intercalation 1**.
- 2 In the **Settings** window for **Particle Intercalation**, locate the **Material** section.
- 3 From the **Particle material** list, choose **LTO, Li4Ti5O12 (Negative, Li-ion Battery) (mat2)**.
- 4 Locate the **Species Settings** section. In the $c_{s,init}$ text field, type `mat2.elpot.cEeqref* soc0_neg`.
- 5 Locate the **Particle Transport Properties** section. In the r_p text field, type `rp_neg`.


Porous Electrode Reaction 1

- 1 In the **Model Builder** window, click **Porous Electrode Reaction 1**.
- 2 In the **Settings** window for **Porous Electrode Reaction**, locate the **Material** section.
- 3 From the **Material** list, choose **LTO, Li4Ti5O12 (Negative, Li-ion Battery) (mat2)**.
- 4 Locate the **Electrode Kinetics** section. In the $i_{0,ref}(T)$ text field, type `i0ref_neg`.


Porous Electrode 1

In the **Model Builder** window, click **Porous Electrode 1**.

Porous Matrix Double Layer Capacitance 1

- 1 In the **Physics** toolbar, click  **Attributes** and choose **Porous Matrix Double Layer Capacitance**.
- 2 In the **Settings** window for **Porous Matrix Double Layer Capacitance**, locate the **Porous Matrix Double Layer Capacitance** section.
- 3 In the C_{dl} text field, type `cd1_neg`.

Porous Electrode 2

- 1 In the **Physics** toolbar, click  **Domains** and choose **Porous Electrode**.
- 2 Select Domain 3 only.
- 3 In the **Settings** window for **Porous Electrode**, locate the **Electrode Properties** section.
- 4 In the σ_s text field, type `sigmas_pos`.

- 5 Locate the **Film Resistance** section. From the **Film resistance** list, choose **Surface resistance**.
- 6 In the R_{film} text field, type `Rfilm_pos`.
- 7 Locate the **Porous Matrix Properties** section. In the ε_s text field, type `eps_pos`.
- 8 In the ε_l text field, type `eps1_pos`.
- 9 Locate the **Effective Transport Parameter Correction** section. From the **Electrolyte conductivity** list, choose **User defined**. In the f_l text field, type `eps1_pos^brug1_pos`.
- 10 From the **Diffusion** list, choose **User defined**. In the f_{DI} text field, type `eps1_pos^brug1_pos`.

Particle Intercalation 1

- 1 In the **Model Builder** window, click **Particle Intercalation 1**.
- 2 In the **Settings** window for **Particle Intercalation**, locate the **Material** section.
- 3 From the **Particle material** list, choose **NCA, LiNi0.8Co0.15Al0.05O2 (Positive, Li-ion Battery) (mat3)**.
- 4 Locate the **Species Settings** section. In the $c_{s,\text{init}}$ text field, type `mat3.elpot.cEeqref*soc0_pos`.
- 5 Locate the **Particle Transport Properties** section. In the r_p text field, type `rp_pos`.


Porous Electrode Reaction 1

- 1 In the **Model Builder** window, click **Porous Electrode Reaction 1**.
- 2 In the **Settings** window for **Porous Electrode Reaction**, locate the **Material** section.
- 3 From the **Material** list, choose **NCA, LiNi0.8Co0.15Al0.05O2 (Positive, Li-ion Battery) (mat3)**.
- 4 Locate the **Electrode Kinetics** section. From the **Kinetics expression type** list, choose **Butler-Volmer**.
- 5 In the i_0 text field, type `i0_pos`.
- 6 Locate the **Active Specific Surface Area** section. From the **Active specific surface area** list, choose **User defined**. In the α_v text field, type `as_pos`.

Porous Electrode 2

In the **Model Builder** window, click **Porous Electrode 2**.

Porous Matrix Double Layer Capacitance 1


- 1 In the **Physics** toolbar, click  **Attributes** and choose **Porous Matrix Double Layer Capacitance**.

- 2 In the **Settings** window for **Porous Matrix Double Layer Capacitance**, locate the **Porous Matrix Double Layer Capacitance** section.
- 3 In the C_{dl} text field, type `cd1_pos`.
- 4 From the **Double-layer area** list, choose **User defined**. In the $\alpha_{v,dl}$ text field, type `as_pos`.

Initial Values 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)>Lithium-Ion Battery (liion)** click **Initial Values 1**.
- 2 In the **Settings** window for **Initial Values**, locate the **Initial Values** section.
- 3 In the *phil* text field, type `-mat2.elpot.Eeq_int1(soc0_neg)`.
- 4 In the *cl* text field, type `cl_init`.

Initial Values 2


- 1 In the **Physics** toolbar, click  **Domains** and choose **Initial Values**.
- 2 Select Domain 3 only.
- 3 In the **Settings** window for **Initial Values**, locate the **Initial Values** section.
- 4 In the *phil* text field, type `-mat2.elpot.Eeq_int1(soc0_neg)`.
- 5 In the *cl* text field, type `cl_init`.
- 6 In the *phis* text field, type `mat3.elpot.Eeq_int1(soc0_pos) - mat2.elpot.Eeq_int1(soc0_neg)`.

Electric Ground 1


Select ground on the current collector of the negative LTO electrode. Set a 10 mV perturbation around the cell voltage of 2.30 V.

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Electric Ground**.
- 2 Select Boundary 1 only.

Electric Potential 1

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Electric Potential**.
- 2 Select Boundary 4 only.
- 3 In the **Settings** window for **Electric Potential**, locate the **Electric Potential** section.
- 4 In the $\phi_{s,bnd}$ text field, type `E_cell_init`.


Harmonic Perturbation 1

- 1 In the **Physics** toolbar, click  **Attributes** and choose **Harmonic Perturbation**.
- 2 In the **Settings** window for **Harmonic Perturbation**, locate the **Harmonic Perturbation** section.

3 In the $\Delta\phi_s$ text field, type E_pert.

Additional Porous Electrode Material I

Add an Additional Porous Electrode Material feature to model the electronic conductor in NCA.

- 1 In the **Physics** toolbar, click  **Domains** and choose **Additional Porous Electrode Material**.
- 2 Select Domain 3 only.
- 3 In the **Settings** window for **Additional Porous Electrode Material**, locate the **Particle Properties** section.
- 4 From the list, choose **Nonintercalating particles**.

Porous Electrode Reaction I


No electrochemical reaction takes place on the electronic conductor, but a double layer capacitance exists.

In the **Model Builder** window, right-click **Porous Electrode Reaction I** and choose **Disable**.

Additional Porous Electrode Material I

In the **Model Builder** window, click **Additional Porous Electrode Material I**.

Porous Matrix Double Layer Capacitance I

- 1 In the **Physics** toolbar, click  **Attributes** and choose **Porous Matrix Double Layer Capacitance**.
- 2 In the **Settings** window for **Porous Matrix Double Layer Capacitance**, locate the **Porous Matrix Double Layer Capacitance** section.
- 3 In the C_{dl} text field, type 1 [F/m²].
- 4 From the **Double-layer area** list, choose **User defined**. In the $\alpha_{v,dl}$ text field, type $cd1vol_cs_pos/1$ [F/m²].

MESH I

- 1 In the **Model Builder** window, under **Component I (comp1)** click **Mesh I**.
- 2 In the **Settings** window for **Mesh**, locate the **Sequence Type** section.
- 3 From the list, choose **User-controlled mesh**.

Size

- 1 In the **Model Builder** window, under **Component I (comp1)**>**Mesh I** click **Size**.
- 2 In the **Settings** window for **Size**, locate the **Element Size** section.

- 3 Click the **Custom** button.
- 4 Locate the **Element Size Parameters** section. In the **Maximum element size** text field, type $1\text{e-}5$.

Size 1

- 1 In the **Model Builder** window, click **Size 1**.
- 2 Select Domains 2 and 3 only.
- 3 In the **Settings** window for **Size**, locate the **Element Size** section.
- 4 Click the **Custom** button.
- 5 Locate the **Element Size Parameters** section.
- 6 Select the **Maximum element size** check box. In the associated text field, type $1\text{e-}6$.

Size 2


- 1 In the **Model Builder** window, click **Size 2**.
- 2 Select Boundaries 2–4 only.
- 3 In the **Settings** window for **Size**, locate the **Element Size** section.
- 4 Click the **Custom** button.
- 5 Locate the **Element Size Parameters** section.
- 6 Select the **Maximum element size** check box. In the associated text field, type $5\text{E-}7$.

STUDY 1

Solve the model for frequencies between 10 mHz and 1 kHz.

- 1 In the **Model Builder** window, click **Study 1**.
- 2 In the **Settings** window for **Study**, locate the **Study Settings** section.
- 3 Clear the **Generate default plots** check box.
- 4 Clear the **Generate convergence plots** check box.

Step 1: Frequency-Domain Perturbation

- 1 In the **Model Builder** window, under **Study 1** click **Step 1: Frequency-Domain Perturbation**.
- 2 In the **Settings** window for **Frequency-Domain Perturbation**, locate the **Study Settings** section.
- 3 In the **Frequencies** text field, type $10^{\{\text{range}(-2, 0.2, 3)\}}$.
- 4 In the **Home** toolbar, click  **Compute**.

STUDY 1

Solution 1 (sol1)

Save the solution of the nonoptimized impedance results.

- 1 In the **Model Builder** window, under **Study 1>Solver Configurations** right-click **Solution 1 (sol1)** and choose **Solution>Copy**.
- 2 Expand the **Solution 1 (sol1)** node.

Not Optimized

- 1 In the **Model Builder** window, expand the **Study 1>Solver Configurations>Solution 1 (sol1)>Stationary Solver 1** node, then click **Study 1>Solver Configurations>Solution 1 - Copy 1 (sol2)**.
- 2 In the **Settings** window for **Solution**, type Not Optimized in the **Label** text field.

RESULTS

Follow these steps to generate [Figure 1](#):

Start by loading experimental data of real and imaginary impedance into a table for plotting purposes. Organize the tables by naming them.

Experimental Impedance Table

- 1 In the **Results** toolbar, click  **Table**.
- 2 In the **Settings** window for **Table**, type Experimental Impedance Table in the **Label** text field.
- 3 Locate the **Data** section. Click  **Import**.
- 4 Browse to the model's Application Libraries folder and double-click the file `li_battery_impedance_Zexp.csv`.


Reference Electrode (RE) Probe Table

- 1 In the **Model Builder** window, under **Results>Tables** click **Probe Table 1**.
- 2 In the **Settings** window for **Table**, type Reference Electrode (RE) Probe Table in the **Label** text field.

Reference Electrode (RE) Potential Probe Plot

- 1 In the **Model Builder** window, under **Results** click **Probe Plot Group 1**.
- 2 In the **Settings** window for **ID Plot Group**, type Reference Electrode (RE) Potential Probe Plot in the **Label** text field.

Nyquist Plots

- 1 In the **Results** toolbar, click  **ID Plot Group**.

- 2 In the **Settings** window for **ID Plot Group**, type Nyquist Plots in the **Label** text field.
- 3 Click to expand the **Title** section. Locate the **Data** section. From the **Dataset** list, choose **Study 1/Not Optimized (sol2)**.
- 4 Locate the **Title** section. From the **Title type** list, choose **None**.
- 5 Locate the **Plot Settings** section.
- 6 Select the **x-axis label** check box. In the associated text field, type $\text{Re}(Z)$
 $([\Omega]m^{²})$.
- 7 Select the **y-axis label** check box. In the associated text field, type $-\text{Im}(Z)$
 $([\Omega]m^{²})$.

Cell Impedance

- 1 Right-click **Nyquist Plots** and choose **Point Graph**.
- 2 In the **Settings** window for **Point Graph**, type Cell Impedance in the **Label** text field.
- 3 Select Boundary 4 only.
- 4 Locate the **y-Axis Data** section. In the **Expression** text field, type $-\text{imag}(Z_{\text{ground}})$.
- 5 Locate the **x-Axis Data** section. From the **Parameter** list, choose **Expression**.
- 6 In the **Expression** text field, type $\text{real}(Z_{\text{ground}})$.
- 7 Click to expand the **Coloring and Style** section. From the **Width** list, choose **2**.
- 8 Click to expand the **Legends** section. Select the **Show legends** check box.
- 9 Find the **Include** subsection. Select the **Label** check box.
- 10 Clear the **Point** check box.
- 11 Clear the **Solution** check box.
- 12 Right-click **Cell Impedance** and choose **Duplicate**.

Impedance NCA vs. Reference

- 1 In the **Model Builder** window, under **Results>Nyquist Plots** click **Cell Impedance 1**.
- 2 In the **Settings** window for **Point Graph**, type Impedance NCA vs. Reference in the **Label** text field.
- 3 Locate the **y-Axis Data** section. In the **Expression** text field, type $-\text{imag}(Z_{\text{ref_NCA}})$.
- 4 Click to expand the **Title** section. From the **Title type** list, choose **None**.
- 5 Locate the **x-Axis Data** section. In the **Expression** text field, type $\text{real}(Z_{\text{ref_NCA}})$.
- 6 Right-click **Impedance NCA vs. Reference** and choose **Duplicate**.



Impedance LTO vs. Reference

- 1 In the **Model Builder** window, under **Results>Nyquist Plots** click **Impedance NCA vs. Reference 1**.
- 2 In the **Settings** window for **Point Graph**, type Impedance LTO vs. Reference in the **Label** text field.
- 3 Locate the **y-Axis Data** section. In the **Expression** text field, type $-\text{imag}(Z_{\text{ref_LTO}})$.
- 4 Locate the **x-Axis Data** section. In the **Expression** text field, type $\text{real}(Z_{\text{ref_LTO}})$.

Experimental Impedance NCA vs. Reference

- 1 In the **Model Builder** window, right-click **Nyquist Plots** and choose **Table Graph**.
The Table Graph plots the experimental data that was imported into the Experimental Impedance Table.
- 2 In the **Settings** window for **Table Graph**, type Experimental Impedance NCA vs. Reference in the **Label** text field.
- 3 Locate the **Data** section. From the **Table** list, choose **Experimental Impedance Table**.
- 4 From the **x-axis data** list, choose **Column 2**.
- 5 From the **Plot columns** list, choose **Manual**.
- 6 In the **Columns** list, select **Column 3**.
- 7 Click to expand the **Legends** section. Select the **Show legends** check box.
- 8 Find the **Include** subsection. Select the **Label** check box.
- 9 Clear the **Headers** check box.




Nyquist Plots

- 1 In the **Model Builder** window, click **Nyquist Plots**.
- 2 In the **Settings** window for **ID Plot Group**, locate the **Legend** section.
- 3 From the **Position** list, choose **Upper left**.
- 4 Locate the **Axis** section. Select the **Preserve aspect ratio** check box.
- 5 In the **Nyquist Plots** toolbar, click  **Plot**.
- 6 Click the  **Zoom Extents** button in the **Graphics** toolbar.

STUDY 1

Add a parametric sweep to investigate the impact four key parameters have on the impedance of NCA versus the reference and how it relates to the experimental measurements.

Parametric Sweep

- 1 In the **Study** toolbar, click  **Parametric Sweep**.
- 2 In the **Settings** window for **Parametric Sweep**, locate the **Study Settings** section.
- 3 Click  **Load from File**.
- 4 Browse to the model's Application Libraries folder and double-click the file `li_battery_impedance_parametric_sweep.txt`.
- 5 In the **Study** toolbar, click  **Compute**.

Parametric Sweep

- 1 In the **Model Builder** window, under **Study 1>Solver Configurations** click **Parametric Solutions 1 (sol3)**.
- 2 In the **Settings** window for **Solution**, type Parametric Sweep in the **Label** text field.

RESULTS

Nyquist Plots

In the **Model Builder** window, under **Results** right-click **Nyquist Plots** and choose **Duplicate**.

Nyquist Plots, Parametric Sweep

Rename the solution for the parametric sweep.

- 1 In the **Model Builder** window, under **Results** click **Nyquist Plots 1**.
- 2 In the **Settings** window for **ID Plot Group**, type Nyquist Plots, Parametric Sweep in the **Label** text field.

Follow these steps to generate [Figure 2](#):

Cell Impedance

- 1 In the **Model Builder** window, expand the **Nyquist Plots, Parametric Sweep** node.
- 2 Right-click **Cell Impedance** and choose **Delete**.

Impedance LTO vs. Reference

In the **Model Builder** window, under **Results>Nyquist Plots, Parametric Sweep** right-click **Impedance LTO vs. Reference** and choose **Delete**.



Impedance NCA vs. Reference

- 1 In the **Model Builder** window, under **Results>Nyquist Plots, Parametric Sweep** click **Impedance NCA vs. Reference**.
- 2 In the **Settings** window for **Point Graph**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Study 1/Parametric Sweep (sol3)**.



- 4 Locate the **Legends** section. From the **Legends** list, choose **Manual**.
- 5 In the table, enter the following settings:

Legends
Impedance NCA vs. Reference, Original Settings
i0_pos=5 Am ⁻²
cd1_pos=0.50 Fm ⁻²
Rfilm_pos=1. [.] 10 ⁻⁵ Ωm ²
cd1vol1_cs_pos=1 [.] 10 ⁴ Fm ⁻³
rp_pos=4 [.] 10 ⁻⁷ m

Nyquist Plots, Parametric Sweep

- 1 In the **Model Builder** window, click **Nyquist Plots, Parametric Sweep**.
- 2 In the **Nyquist Plots, Parametric Sweep** toolbar, click  **Plot**.
- 3 Click the  **Zoom Extents** button in the **Graphics** toolbar.

ADD STUDY


- 1 In the **Home** toolbar, click  **Add Study** to open the **Add Study** window.
- 2 Go to the **Add Study** window.
- 3 Find the **Studies** subsection. In the **Select Study** tree, select **Preset Studies for Selected Physics Interfaces>AC Impedance, Initial Values**.
- 4 Click **Add Study** in the window toolbar.
- 5 In the **Home** toolbar, click  **Add Study** to close the **Add Study** window.



STUDY 2

- 1 In the **Model Builder** window, click **Study 2**.
- 2 In the **Settings** window for **Study**, locate the **Study Settings** section.
- 3 Clear the **Generate default plots** check box.
- 4 Clear the **Generate convergence plots** check box.

Parameter Estimation

Select i0_pos, Rfilm_pos, cd1_pos, and cs1vol1_cs_pos as the four parameters to be optimized.

- 1 In the **Study** toolbar, click  **Optimization** and choose **Parameter Estimation**.
Import the experimental data in csv format for the impedance of the NCA electrode versus the reference.

- 2 In the **Settings** window for **Parameter Estimation**, locate the **Experimental Data** section.
- 3 In the **Filename** text field, type `li_battery_impedance_Zexp.csv`.
- 4 Click  **Refresh**.
- 5 Locate the **Data Column Settings** section. In the table, click to select the cell at row number 1 and column number 2.
- 6 From the drop-down list, choose **Frequency**.
The second column of the experimental data contains the real-impedance global value.
- 7 In the table, click to select the cell at row number 2 and column number 3.
- 8 In the **Model expression** text field, type `comp1.intop1(real(Z_ref_NCA))`.
- 9 In the **Variable name** text field, type `Real_impedance`.
- 10 From the **Scale** list, choose **Manual**.
- 11 In the **Scale value** text field, type `1e-3`.
The third column of the experimental data contains the imaginary-impedance global value.
- 12 In the table, click to select the cell at row number 3 and column number 3.
- 13 In the **Model expression** text field, type `-comp1.intop1(imag(Z_ref_NCA))`.
- 14 In the **Variable name** text field, type `Imaginary_impedance`.
- 15 From the **Scale** list, choose **Manual**.
- 16 In the **Scale value** text field, type `1e-3`.
- 17 Locate the **Estimated Parameters** section. Click  **Add** four times.

18 Row by row, select the parameter name in the first column, then set the corresponding initial value, scale, and bounds as follows:


Parameter name	Initial value	Scale	Lower bound	Upper bound
i0_pos (Exchange current density positive electrode)	1 [A/m ²]	1	1	5
Rfilm_pos (Film resistance positive electrode)	1 e-4 [m ² /S]	1 e-3	1 e-6	5 e-3
cdl_pos (Double layer capacitance positive electrode material)	0.5 [F/m ²]	1	0.10	1
cdvol_cs_pos (Volumetric capacitance of electronic conductor in positive electrode)	1 e5 [F/m ³]	1 e6	1 e5	3 e5

The IPOPT method allows the use of lower and upper bounds.

- 19 Locate the **Parameter Estimation Method** section. From the **Method** list, choose **IPOPT**.
- 20 Find the **Solver settings** subsection. From the **Least-squares time/parameter method** list, choose **Use only least-squares data points**.
- 21 Click to expand the **Output While Solving** section. Select the **Plot** check box.
- 22 From the **Plot group** list, choose **Default**.

Solution 10 (sol10)

Choose the numeric gradient method.

- 1 In the **Study** toolbar, click  **Show Default Solver**.
- 2 In the **Model Builder** window, expand the **Solution 10 (sol10)** node, then click **Optimization Solver 1**.
- 3 In the **Settings** window for **Optimization Solver**, locate the **Optimization Solver** section.
- 4 From the **Gradient method** list, choose **Numeric**.
- 5 In the **Difference interval** text field, type 5e-4.


RESULTS

It is common to monitor the optimization, especially if the optimization is time consuming. This makes it possible to stop the optimization if the fit seems adequate or if the optimization settings need to be improved.

The optimized parameters can be monitored using Global Probes.

First, a table is generated that collects the parameters during the optimization.


Optimized Parameters Table

- 1 In the **Results** toolbar, click  **Table**.
- 2 In the **Settings** window for **Table**, type *Optimized Parameters Table* in the **Label** text field.

DEFINITIONS (COMP1)

Thereafter, the global probes are made.

Exchange Current Density NCA

- 1 In the **Definitions** toolbar, click  **Probes** and choose **Global Variable Probe**.
- 2 In the **Settings** window for **Global Variable Probe**, type *Exchange Current Density NCA* in the **Label** text field.
- 3 Locate the **Expression** section. In the **Expression** text field, type `linpoint(i0_pos)`.
- 4 Click to expand the **Table and Window Settings** section. From the **Output table** list, choose **Optimized Parameters Table**.
- 5 Right-click **Exchange Current Density NCA** and choose **Duplicate**.

Double-Layer Capacitance NCA

- 1 In the **Model Builder** window, under **Component 1 (comp1)>Definitions** click **Exchange Current Density NCA 1 (var2)**.
- 2 In the **Settings** window for **Global Variable Probe**, type *Double-Layer Capacitance NCA* in the **Label** text field.
- 3 Locate the **Expression** section. In the **Expression** text field, type `linpoint(cd1_pos)`.
- 4 Right-click **Double-Layer Capacitance NCA** and choose **Duplicate**.

Film Resistance NCA

- 1 In the **Model Builder** window, under **Component 1 (comp1)>Definitions** click **Double-Layer Capacitance NCA 1 (var3)**.
- 2 In the **Settings** window for **Global Variable Probe**, type *Film Resistance NCA* in the **Label** text field.
- 3 Locate the **Expression** section. In the **Expression** text field, type `linpoint(Rfilm_pos)`.
- 4 Right-click **Film Resistance NCA** and choose **Duplicate**.

Vol. Double-Layer Cap. Pos. Electronic Conductor

- 1 In the **Model Builder** window, under **Component 1 (comp1)>Definitions** click **Film Resistance NCA 1 (var4)**.

- 2 In the **Settings** window for **Global Variable Probe**, type Vol. Double-Layer Cap. Pos. Electronic Conductor in the **Label** text field.
- 3 Locate the **Expression** section. In the **Expression** text field, type `linpoint(cd1vol_cs_pos)`.

RESULTS

Follow these steps to set up a plot group that also enables graphical monitoring of optimization:



Nyquist Plots, Parametric Sweep

In the **Model Builder** window, under **Results** right-click **Nyquist Plots, Parametric Sweep** and choose **Duplicate**.



Nyquist Plots, Optimization

- 1 In the **Model Builder** window, under **Results** click **Nyquist Plots, Parametric Sweep 1**.
- 2 In the **Settings** window for **ID Plot Group**, type Nyquist Plots, Optimization in the **Label** text field.
- 3 Locate the **Data** section. From the **Dataset** list, choose **None**.

Impedance NCA vs. Reference

- 1 In the **Model Builder** window, expand the **Nyquist Plots, Optimization** node, then click **Impedance NCA vs. Reference**.
- 2 In the **Settings** window for **Point Graph**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Study 2/Solution 10 (sol10)**.
- 4 Locate the **Coloring and Style** section. From the **Width** list, choose **1**.
- 5 Find the **Line markers** subsection. From the **Marker** list, choose **Square**.
- 6 Locate the **Legends** section. From the **Legends** list, choose **Automatic**.
- 7 Click the  **Zoom Extents** button in the **Graphics** toolbar.
- 8 In the **Nyquist Plots, Optimization** toolbar, click  **Plot**.


Experimental Impedance NCA vs. Reference

- 1 In the **Model Builder** window, click **Experimental Impedance NCA vs. Reference**.
- 2 In the **Settings** window for **Table Graph**, locate the **Coloring and Style** section.
- 3 Find the **Line markers** subsection. From the **Marker** list, choose **Square**.
- 4 Click the  **Zoom Extents** button in the **Graphics** toolbar.
- 5 In the **Nyquist Plots, Optimization** toolbar, click  **Plot**.

STUDY 2

Thereafter, select the plot group and table you want to monitor in the Optimization study step and compute.

Parameter Estimation

- 1 In the **Model Builder** window, under **Study 2** click **Parameter Estimation**.
- 2 In the **Settings** window for **Parameter Estimation**, locate the **Output While Solving** section.
- 3 From the **Plot group** list, choose **Nyquist Plots, Optimization**.
- 4 In the **Home** toolbar, click  **Compute**.



Optimized

Rename the solution of the optimization.

- 1 In the **Model Builder** window, under **Study 2>Solver Configurations** click **Solution 10 (sol10)**.
- 2 In the **Settings** window for **Solution**, type **Optimized** in the **Label** text field.

RESULTS

Nyquist Plots, Optimization

- 1 In the **Model Builder** window, under **Results** click **Nyquist Plots, Optimization**.
- 2 In the **Nyquist Plots, Optimization** toolbar, click  **Plot**.
- 3 Click the  **Zoom Extents** button in the **Graphics** toolbar.

To control the parameters in the last iteration, consult the Optimized Parameters Table that gives you the optimized parameters.